**BI/AI** = Basic/Advanced Interactive **cBI/cAI** = Commercial Basic/Advanced Interactive

1. Remote Monitoring and Control

2. Customized Email/Text Notifications

4. empower

5. Video Monitoring

REMOTE MONITORING AND CONTROL	BI	: AI	: cBI	: cA
<b>Remote Arming/Disarming</b> - Arm/disarm system remotely via web or mobile apps.	<b>~</b>	V	~	•
<b>System Status and Summary of Recent Activity</b> - View an at-a-glance summary showing the current system status and any recent activity at your property via web or mobile apps.	<b>~</b>	<b>~</b>	•	~
<b>User Code Management</b> - Add/delete/edit user codes remotely, and track which users arm/disarm the system at what times. For systems with multiple partitions, choose which partition(s) each user code can access.	<b>~</b>	<b>~</b>	•	•
<b>Searchable 60-Day Event History</b> - Search a 60-day history of events reported by the system, including alarms and other activity, via web or mobile apps. Customize the time frame of the search, and filter by device or event type. Download results as HTML or Excel files.	•	~	•	•
<b>Multiple Permission-Based Web Logins</b> - Create different "sub-users" for the account and grant varying levels of permissions for each user to view/change various settings in the Alarm.com web interface.	<b>~</b>	~	~	~
<b>Multiple Partition Support</b> - For compatible GE Concord/NX panels with multiple partitions, you can arm or disarm individual partitions via the web, add and assign new user codes to a specific set of partitions, see which sensors are in which partition, and filter the online event history by partition. Customers with a commercial service plan can also set up unique Arming Supervision schedules for each partition.	<b>~</b>	~	•	
CUSTOMIZED EMAIL/TEXT NOTIFICATIONS	ВІ	: AI	: cBI	; cA
<b>Alarms</b> - Receive email/text notifications for any type of alarm reported by the system. Using the web interface, customize which types of alarms result in notifications and also details such as time and date. (These automated alarm notifications are in addition to and independent of the emergency response services provided by the central monitoring station.)	•	<b>~</b>	•	•
<b>Arming/Disarming</b> - Receive email/text notifications when the system is armed or disarmed. For armings/disarmings performed at the panel, the event notification includes the person's name whose user code was entered at the panel. For armings or disarmings performed using a keychain remote, the notification indicates which remote was used (ie: Bill's Keychain Remote).	<b>~</b>	<b>~</b>	•	~
<b>System Events</b> - Receive email/text notifications for power failures, sensor tampers/malfunctions, panel low battery and other kinds of system events.	<b>~</b>	~	~	~
<b>No-Show Alerts **NEW**</b> - Receive email/text message notifications if a certain person did not disarm their security system at a certain date/time.	~	~	~	•
<b>Arming Reminders</b> - Receive email/text notifications if the system has not been armed by a particular time on a given day. (Not available on commercial service plans, which include Arming Supervision, a similar but more robust arming reminder feature designed for commercial users.)	<b>~</b>	•		
<b>24x7 Sensor Activity</b> - Receive email/text notifications for non-alarm activity reported by door, window, cabinet, motion, and other sensors when the system is disarmed. Alarm.com module reports all sensor and system activity 24/7 to Alarm.com, and Alarm.com sends alerts to selected recipients from the user's address book if it detects user-defined activity. Users can specify times during which sensor activity should result in a notification (ie: receive alert if front door is opened between 9-5/M-F).		~		•
<b>Sensor-Left-Open</b> - Receive email/text message if a particular door, cabinet, or window sensor is left open for an extended period during specified time frames (ie: receive an alert if the garage door is left open for more than 2 hours between 9-5/M-F).		<b>~</b>		•

ever new video is recorded. Receive remote video storage - all without needing a security control panel.

<sup>\*</sup> Please note that the availability of some features may vary according to system and firmware version.

<sup>\*\*</sup> emPower add-ons require an emPower-enabled Alarm.com GSM module and compatible emPower devices. emPower functionality may vary by control panel. Contact Alarm.com for more details.